

Kids Wireless Headphones

USER MANUAL



Bluetooth 5.0

Overview



Play / Pause

Answer / Hang Up



Next Track

Volume Down



ON / OFF



Previous Track

Volume Up



M

Mute

FM

Card Slot

Micro-SD Card
Not Included



Input 5V / 1A



Warning:

Do not charge with a fast charger with voltage $>5V$ and current $>1.2A$, otherwise it will cause damage and other serious conditions.




Bluetooth Connection

 +  +  > 3.0s

Bluetooth Connection


Press and Hold "ON" for more than 3 sec.

If not connected, the headphone will enter pairing mode automatically after it is powered on.
























Connect Bluetooth Device

Choose "P47" to Connect



LED Indicator

LED	Blue	Red
On		
Fast		
Slow		

Headphone mode	LED Status
 Power on	 x2
 Power off	 x2
No device connected	 Slow
 BT Pairing	 Fast
 BT Connected	 On
 Low battery	 Slow
 Charging Complete	 On
 Charging in Progress	 On

Technical Specifications

Driver Size:	40mm
Dynamic frequency response range:	20Hz~22kHz
Maximum SPL:	85dB@1kHz
Microphone sensitivity@1 kHz dB v/pa:	-42dB (±3)
Impedance:	16Q
Bluetooth transmitted modulation:	GFSK TT/4-DQPSK 8DPSK
Bluetooth profiles:	HFP v1.7, A2DP v1.3, AVRCP v1.5
Bluetooth version:	5.0
Battery type:	440931
Polymer Li-ion Battery:	3.8V 250mA
Charging time:	<4hr
Music play time with BT on:	>8hr
Talk time with BT on:	8hr



Lalarma.com